

QUAD

Installation instructions for the Quad 33 control unit and Quad FM3 stereo tuner.

- 1) Remove the four rubber feet from the underside of each unit.**
- 2) Remove the metal case from each unit.**
- 3) Slide the metal cases into the sleeve and use the four $\frac{5}{8}$ " long screws provided to secure the feet to the cases through the slots in the underside of the sleeve.**
- 4) Insert the units through the front of the sleeve and retain with the cover securing screws. Do not overtighten.**
- 5) IMPORTANT. The feet must only be secured with the $\frac{5}{8}$ " screws provided. If other screws are used, the units may be damaged.**

QUAD is a registered trademark.

**Acoustical Manufacturing Co. Ltd.
Huntingdon, England Tel. (0480) 52561/2.**

4/73/1K