

Quick Guide to Handset Operation of 561

Action	561 as Controller	DSP Speaker as Controller
Source Selection	CD, RADIO etc.	CD, RADIO etc.
Go to Standby	Off	Off
Volume	Volume ▲ ▼	Volume ▲ ▼
Mute	Mute	Mute
Headphone Volume (with tape module only)	Function + Volume ▲ ▼	Function + Volume ▲ ▼
Change Display	Display	Not available
Change DSP Preset	•	Function + •
Move to next or previous menu	Menu ◀ ▶	Function + Menu ◀ ▶
Change the value of this menu	Menu ▲ ▼	Function + Menu ▲ ▼
Store settings as a new DSP Preset or over an existing one	Store	Function + Store
Associate the current DSP Preset with the current Source	Function + Store	Function + Mute
Delete an unwanted User Preset	Clear (Held down)	Function + Clear (Held down)

Quick Guide to Special Features on 561

Special Feature	Front Panel key
Turn on or off Diagnostics	Hold down Copy key in standby
Lock or Unlock menus	Hold down Preset key in Standby
Enter or Exit Gain/Sub mode	Hold down Mute key in Standby
Check Software version etc.	Press Display in Standby
Change from feet/inches to metres	Hold down ▼ key in Standby
Enter Type (Caution! Resets!)	Hold down ▲ key in Standby
Enter Calibration	Hold down Off key in Standby
Exit Calibration or Type	Press Off key